



PASY KLINOWE O PROFILU WYSOKIM

Oznaczenie wielkości przekroju pasa		Szerokość skuteczna lp [mm]	Wymiary orientacyjne [mm]		Przeliczenie długości pasa		Ciężar kg/mb
WZMOCNIONE	"STANDARD"		lo	ho	Lz=Lp + ... [mm]	Lw=Lp- ... [mm]	
SPZ	SPZ	8,5	9,7	8	Lz = Lp + 13	Lw = Lp - 30	~0,078
SPA	SPA	11	12,7	10	Lz = Lp + 18	Lw = Lp - 39	~0,139
SPB	-	14	16,3	13	Lz = Lp + 22	Lw = Lp - 60	~0,228
SPC	SPC	19	22	18	Lz = Lp + 30	Lw = Lp - 73	~0,426
13,4 x 10,7	-	11,5	13,4	10,7	Lz = Lp + 17	Lw = Lp - 45	~0,153